


# HORNO ELÉCTRICO


## ESSENZA





Electric oven // Fours électriques // Forno elétrico // Forni elettrico // Elektrischer ofen


**W Potencia 800W**  
Energy used // Puissance // Poder // Potenza // Potenz

9L. **9L DE CAPACIDAD**  
Capacity / Capacité / Capacidade / Capacità / Tankinhalt

 **COCCIÓN SUPERIOR E INFERIOR**  
Upper & Lower / Inférieure et supérieure / Sup. e inferior / Super. Inferiore / Oberer und unterer


 **COCCIÓN INFERIOR**  
Lower / Inférieure / Inferior / Inferiore / Unterer


 **COCCIÓN SUPERIOR**  
Upper / Supérieure / Superior / Superiore / Oberer

 **30 MINUTOS TEMPORIZADOR**  
Minute timer / Minuterie minute / Cronômetro de minuto / Timer minuto / Minuten-Timer


 **CON DOBLE CRISTAL**  
Double door glass / Double vitrage / Vidros duplos / Doppi vetri / Doppelglas

 **INCLUYE BANDEJA Y REJILLA**  
Includes plate and grill / Comprend plateau et grill / Includi bandeja e grelha / Comprende padella e griglia / Ai përfshin pfanne und gitter

 **ASA DE ACERO INOXIDABLE**  
Stainless steel handle / Poignée en acier inoxydable / Alça de aço inoxidável / Manico in acciaio inossidabile / Griff aus Edelstahl


 **INDICADOR LUMINOSO**  
Light indicator / Voyant / Luz indicadora / Spia luminosa / Kontrollleuchte

 **SEÑAL FIN DE COCINADO**  
Cooking end signal / Signal de fin de cuisson / Sinal de fim de cozedura / Segnale di fine cottura / Kochende -Signal

 **COLOR BLANCO**  
White color / Couleur blanche / Cor branca / Colore bianco / Weiße Farbe

 **FÁCIL DE USAR Y DE LIMPIAR**  
Easy to use and clean / Facile à utiliser et nettoyage / Fácil de usar e limpar / Facile da usare e pulito / Einfach zu bedienen und zu reinigen

 220-240V~ 50/60Hz

 **Embalaje 2**  
Packing // Emballage // Embalagem // Imballaggio // Verpackung